Maintenance Plan

SLK Multy Product Family

☐ SLK Multy Aktiv ☐ + SLK Multy Conversion Kit Universal

☐ SLK Multy Aktiv e ☐ + SLK Multy Conversion Kit Universal

☐ SLK Multy Universal ☐ + SLK Multy Conversion Kit Aktiv

☐ SLK Multy Universal e ☐ + SLK Multy Conversion Kit Aktiv

Serial number : _ _ _ _ _ _ _ _ _ _ _ **Date of manufacture:** _ _ / _ _ _ _

SLK Vertriebsgesellschaft mbH
Am Herdicksbach 18
D-45731 Waltrop

Telefon: +49 (0) 2309 - 91545 - 0
Telefax: +49 (0) 2309 - 91545 - 999
E-Mail: info@slk-gmbh.de
Internet: www.slk-gmbh.de

@SLK Medizintechnik
slk_medizintechnik

Please use the **current maintenance plan** from the SLK website **www.slk-gmbh.de** (download area) for documentation.

Pos.	Object		OK	not OK	Remarks	Repaired on:
1	Hoist in original condition					
2	Compatibility certificate for accessory and device combinations is available					
3	User guide available					
4	Type labels present and legible					
5	Casters	• turn easily				
		• pivotable by 360°				
		• undamaged				
		• Fastening screws tightened firmly				
		• Brakes in functional condition				
6	Welding seams ok/ no crack formations/ no deformations	• Base				
		• Mast				
		• Lifting arm (also notice long hole formation on the CSP)				
		• Pusher bar				
		• Motor brackets				
		• Spreader bar/footboard/shin support (depending on model)				
7	No surface damage or corrosion					
8	Function of the base expansion works easily					
9	Bolt with SL clip in proper condition (replace in case if marks are present)					
10	Bolt for fixating the lifting arm (40mm long) and the mast (60mm long) are present and in proper condition (replace in case marks are present)					
11	All screws tightened securely, especially:	• between the base and mast				
		• between the mast and lifting arm (100 Nm tightening torque)				
		• between the central tube and feet (100 Nm tightening torque)				
	In the case of circlip fastening:	• All 4 ciclips are present and correctly positioned on the foot fixings.				
12	Hoist bolt with collar for the spreader bar has a collar height of min. 4 mm. Double check the measurement with a slider gauge and enter it under “Remarks” (depending on model)					
13	Teflon washer is present between the hoist bolt and the spreader bar, min. 1 mm thickness or replace otherwise					
14	Gas pressure spring is functional					
15	Folding mechanism is functional					
16	Pusher bar is screwed on					

Serial number : _ _ _ _ _ _ _ _ _ _ _

Pos.	Object	OK	not OK	Remarks	Repaired on:
17	Plug on the spreader bar is present / spring locks and plugs present on spreader bar (if applicable)				
18	The soft shin pad has a type plate and service label that are present and legible. The pad shows no tears, holes, cuts, significant signs of wear, fabric structure shifts, or deformation due to heat. No torn, worn, or frayed seams are visible. The service label has been marked.				
Electrical system					
19	All cables undamaged and connected				
20	Emergency-stop button present and functional (no function while emergency-stop button is pressed, reactivation only by turning)				
21	Charger is present and undamaged, Connections clean, orange control lamp during charging				
22	Charging function available				
23	No lift function during charging				
24	Tipping operation of the hand control works (releasing the hand control stops the lift operation)				
25	No lifting function when the bolt in the mast is not installed correctly. **Test: Remove bolt > all lifting functions must be disabled**				
26	Control sticker **"Membrane replaced"** on the safety box applied / present.				
27	Hand control including cable and strain relief are undamaged, control lamps work (if present)				
28	Seal ring present on the plug of the hand control				
29	Control box screwed on tightly				
30	Battery pack without external damage or deformation, connections clean, battery pack locking mechanism engages (It is recommended to replace the battery pack after 4 years)				
31	Electrical control by means of the buttons on the control box works				
32	Indicators/displays function				
33	Both limit switches function (drive switches off at the top and bottom)				
34	No remarkable noises in the drive motor				
35	Mechanical emergency lowering works				
36	Grease deposits removed from the thrust rod				
37	Electrical base expansion works (if present)				
38	Test of the entire lifting cycle pursuant to EN 10535 Annex B1 Multy Universal: with maximum nominal load of the hoist Multy Aktiv: with 50% of the maximum nominal load of the hoist				

☐ **The patient hoist can be used.**

☐ **The patient lift must no longer be used and must be repaired before further use.**
A corresponding label has been appended. The person responsible has been informed and hereby confirms this with their signature: _____

Position of the responsible person: _____ Name in printed letters: _____

Date: _____ Signature of tester: _____

Next servicing: _____ Name in printed letters: _____

☐ **All defects have been repaired professionally. The patient hoist can be used.**

Date: _____ Signature of tester: _____

Next servicing: _____ Name in printed letters: _____